

CISCO - SG 300-20 DUAL REDUNDANCY - 10 DANTE 13_01_2014

This configuration is optimized for DANTE. In a mixed traffic production (VoIP, video....) this configuration can require modification. DV2 do not provide consultation service for wider network traffic profile.

QoS

The screenshot displays the Cisco SG300-20 web management interface. The left sidebar shows a navigation tree with 'Quality of Service' expanded to 'QoS Properties'. The main content area is titled 'QoS Properties' and includes the following elements:

- QoS Mode:** Radio buttons for 'Disable', 'Basic', and 'Advanced' (selected).
- Buttons:** 'Apply' and 'Cancel'.
- Interface CoS Configuration Table:** A table with columns 'Entry No.', 'Interface', and 'Default CoS'. It shows 20 entries, all with a Default CoS of 0. A filter bar above the table reads 'Filter: Interface Type equals to Port' with a 'Go' button.
- Buttons:** 'Copy Settings...', 'Edit...', and 'Restore Defaults' at the bottom of the table.

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

SG300-20 20-Port Gigabit Managed Switch - Windows Internet Explorer

http://192.168.1.254/csc6b64841/home

Small Business Language: English

SG300-20 20-Port Gigabit Managed Switch

- Getting Started
- Status and Statistics
- Administration
- Port Management
- Smartport
- VLAN Management
- Spanning Tree
- MAC Address Tables
- Multicast
- IP Configuration
- Security
- Access Control
- Quality of Service**
 - General
 - QoS Properties
 - Queue**
 - CoS/802.1p to Queue
 - DSCP to Queue
 - Bandwidth
 - Egress Shaping Per Queue
 - VLAN Ingress Rate Limit
 - TCP Congestion Avoidance
 - QoS Basic Mode
 - QoS Advanced Mode
 - QoS Statistics
- SNMP

Queue

Queue Table

Queue	Scheduling Method			
	Strict Priority	WRR	WRR Weight	% of WRR Bandwidth
1	<input checked="" type="radio"/>	<input type="radio"/>	1	
2	<input type="radio"/>	<input type="radio"/>	2	
3	<input type="radio"/>	<input type="radio"/>	4	
4	<input type="radio"/>	<input type="radio"/>	8	

Queue 1 has the lowest priority, queue 4 has the highest priority.

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

Small Business Language: English

SG300-20 20-Port Gigabit Managed Switch

- Getting Started
- Status and Statistics
- Administration
- Port Management
- Smartport
- VLAN Management
- Spanning Tree
- MAC Address Tables
- Multicast
- IP Configuration
- Security
- Access Control
- Quality of Service**
 - General
 - QoS Properties
 - Queue
 - CoS/802.1p to Queue
 - DSCP to Queue**
 - Bandwidth
 - Egress Shaping Per Queue
 - VLAN Ingress Rate Limit
 - TCP Congestion Avoidance
 - QoS Basic Mode
 - QoS Advanced Mode
 - QoS Statistics
- SNMP

DSCP to Queue

DSCP to Queue Table

Ingress DSCP	Output Queue	Ingress DSCP	Output Queue	Ingress DSCP	Output Queue	Ingress DSCP	Output Queue
0 (BE)	1	16 (CS2)	1	32 (CS4)	1	48 (CS6)	1
1	1	17	1	33	1	49	1
2	1	18 (AF21)	1	34 (AF41)	1	50	1
3	1	19	1	35	1	51	1
4	1	20 (AF22)	1	36 (AF42)	1	52	1
5	1	21	1	37	1	53	1
6	1	22 (AF23)	1	38 (AF43)	1	54	1
7	1	23	1	39	1	55	1
8 (CS1)	2	24 (CS3)	1	40 (CS5)	1	56 (CS7)	4
9	1	25	1	41	1	57	1
10 (AF11)	1	26 (AF31)	1	42	1	58	1
11	1	27	1	43	1	59	1
12 (AF12)	1	28 (AF32)	1	44	1	60	1
13	1	29	1	45	1	61	1
14 (AF13)	1	30 (AF33)	1	46 (EF)	3	62	1
15	1	31	1	47	1	63	1

Queue 1 has the lowest priority, queue 4 has the highest priority.

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

Priority	Usage	DSCP priority value
High	Time critical clock sync (PTP) packets	56
Medium	Audio packets	46
Low	(reserved)	8
None	Other traffic	0

The screenshot displays the configuration interface for a Cisco SG300-20 switch. The left sidebar shows a navigation menu with 'Quality of Service' expanded to 'Global Settings'. The main content area shows the following configuration options:

- Trust Mode:**
 - CoS/802.1p
 - DSCP
 - CoS/802.1p-DSCP
- Default Mode Status:**
 - Trusted
 - Not Trusted
- Override Ingress DSCP:** Enable

At the bottom of the configuration area, there are three buttons: 'DSCP Override Table', 'Apply', and 'Cancel'.

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

VLAN

The screenshot shows the Cisco Small Business SG300-20 20-Port Gigabit Managed Switch web interface. The browser window title is "SG300-20 20-Port Gigabit Managed Switch - Windows Internet Explorer". The address bar shows the URL "http://192.168.1.254/csc6b64841/home.htm". The interface includes a navigation menu on the left with categories like Administration, Port Management, Smartport, and VLAN Management. The main content area is titled "Create VLAN" and features a "VLAN Table" with the following data:

<input type="checkbox"/>	VLAN ID	VLAN Name	Type
<input type="checkbox"/>	1		Default
<input type="checkbox"/>	2	Secondary	Static

Below the table are buttons for "Add...", "Edit...", and "Delete". The footer of the page contains the copyright notice: "© 2010-2013 Cisco Systems, Inc. All Rights Reserved."

Small Business cisco Language: English Logout About Help

SG300-20 20-Port Gigabit Managed Switch

- Getting Started
- Status and Statistics
- Administration
 - System Settings
 - Console Settings
 - Management Interface
 - User Accounts
 - Idle Session Timeout
 - Time Settings
 - System Log
 - File Management
 - Upgrade/Backup Firmware
 - Active Image
 - Download/Backup Configuration
 - Configuration Files Properties
 - Copy/Save Configuration
 - DHCP Auto Configuration
 - Reboot
 - Diagnostics
 - Discovery - Bonjour
 - Discovery - LLDP
 - Discovery - CDP
 - Ping
 - Traceroute
 - Port Management
 - Smartport
 - VLAN Management
 - Default VLAN Settings
 - Create VLAN
 - Interface Settings
 - Port to VLAN
 - Port VLAN Membership
 - GVRP Settings
 - VLAN Groups
 - Voice VLAN
 - Access Port Multicast TV VLAN
 - Customer Port Multicast TV VLAN

Interface Settings

Interface Setting Table Showing 1-20 of 20 All per page

Filter: Interface Type equals to Port Go

Entry No.	Interface	Interface VLAN Mode	Administrative PVID	Frame Type	Ingress Filtering
<input type="radio"/>	1	GE1	Access	1	Admit All Enabled
<input type="radio"/>	2	GE2	Access	1	Admit All Enabled
<input type="radio"/>	3	GE3	Access	1	Admit All Enabled
<input type="radio"/>	4	GE4	Access	1	Admit All Enabled
<input type="radio"/>	5	GE5	Access	1	Admit All Enabled
<input type="radio"/>	6	GE6	Access	1	Admit All Enabled
<input type="radio"/>	7	GE7	Access	1	Admit All Enabled
<input type="radio"/>	8	GE8	Access	1	Admit All Enabled
<input type="radio"/>	9	GE9	Access	2	Admit All Enabled
<input type="radio"/>	10	GE10	Access	2	Admit All Enabled
<input type="radio"/>	11	GE11	Access	2	Admit All Enabled
<input type="radio"/>	12	GE12	Access	2	Admit All Enabled
<input type="radio"/>	13	GE13	Access	2	Admit All Enabled
<input type="radio"/>	14	GE14	Access	2	Admit All Enabled
<input type="radio"/>	15	GE15	Access	2	Admit All Enabled
<input type="radio"/>	16	GE16	Access	2	Admit All Enabled
<input type="radio"/>	17	GE17	Access	1	Admit All Enabled
<input type="radio"/>	18	GE18	Access	2	Admit All Enabled
<input type="radio"/>	19	GE19	Access	1	Admit All Enabled
<input type="radio"/>	20	GE20	Access	2	Admit All Enabled

Copy Settings... Edit...

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

SG300-20 20-Port Gigabit Managed Switch - Windows Internet Explorer

http://192.168.1.254/csc6b64841/home

Small Business cisco Language: English Logout About Help

SG300-20 20-Port Gigabit Managed Switch

- Getting Started
- Status and Statistics
- Administration
 - System Settings
 - Console Settings
 - Management Interface
 - User Accounts
 - Idle Session Timeout
 - Time Settings
 - System Log
 - File Management
 - Upgrade/Backup Firmware
 - Active Image
 - Download/Backup Configuration
 - Configuration Files Properties
 - Copy/Save Configuration
 - DHCP Auto Configuration
 - Reboot
 - Diagnostics
 - Discovery - Bonjour
 - Discovery - LLDP
 - Discovery - CDP
 - Ping
 - Traceroute
 - Port Management
 - Smartport
 - VLAN Management
 - Default VLAN Settings
 - Create VLAN
 - Interface Settings
 - Port to VLAN
 - Port VLAN Membership
 - GVRP Settings
 - VLAN Groups
 - Voice VLAN
 - Access Port Multicast TV VLAN
 - Customer Port Multicast TV VLAN

Port to VLAN

Filter: VLAN ID equals to 2 AND Interface Type equals to Port Go

Interface	GE1	GE2	GE3	GE4	GE5	GE6	GE7	GE8	GE9	GE10	GE11	GE12	GE13	GE14	GE15	GE16	GE17	GE18	GE19	GE20
Access	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Trunk	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
General	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Customer	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Forbidden	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
Excluded	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Tagged	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Untagged	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Multicast TV VLAN	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
PVID	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Apply Cancel Port VLAN Membership Table

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

STP

Protocol Disabled

Small Business
cisco SG300-20 20-Port Gigabit Managed Switch

Language: English Logout About Help

Getting Started
Status and Statistics
Administration
Port Management
Smartport
VLAN Management
Spanning Tree
STP Status & Global Settings
STP Interface Settings
RSTP Interface Settings
MSTP Properties
VLAN to MSTP Instance
MSTP Instance Settings
MSTP Interface Settings
MAC Address Tables
Multicast
IP Configuration
Security
Access Control
Quality of Service
SNMP

STP Status & Global Settings

Global Settings

Spanning Tree State: Enable

STP Operation Mode: Classic STP
 Rapid STP
 Multiple STP

BPDU Handling: Filtering
 Flooding

Path Cost Default Values: Short
 Long

Bridge Settings

Priority: (Range: 0 - 61440, Default: 32768)

Hello Time: sec (Range: 1 - 10, Default: 2)

Max Age: sec (Range: 6 - 40, Default: 20)

Forward Time: sec (Range: 4 - 30, Default: 15)

Designated Root

Bridge ID: 32768-08:d0:9f:6d:1d:41

Root Bridge ID: 32768-08:d0:9f:6d:1d:41

Root Port: 0

Root Path Cost: 0

Topology Changes Counts: 0

Last Topology Change: 0D/0H/23M/5S

Apply Cancel

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

Small Business Save cisco Language: English Logout About Help

SG300-20 20-Port Gigabit Managed Switch

- Getting Started
- Status and Statistics
- Administration
- Port Management
- Smartport
- VLAN Management
- Spanning Tree
 - STP Status & Global Settings
 - STP Interface Settings
 - RSTP Interface Settings
 - MSTP Properties
 - VLAN to MSTP Instance
 - MSTP Instance Settings
 - MSTP Interface Settings
- MAC Address Tables
- Multicast
- IP Configuration
- Security
- Access Control
- Quality of Service
- SNMP

STP Interface Settings

STP Interface Setting Table

Filter: Interface Type equals to

Entry No.	Interface	STP	Edge Port	Root Guard	BPDU Guard	BPDU Handling	Port Role	Path Cost	Priority	Port State	Designated Bridge ID	Designated P
<input type="radio"/>	1	GE1	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	2	GE2	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	3	GE3	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	4	GE4	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	5	GE5	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	6	GE6	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	7	GE7	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	8	GE8	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	9	GE9	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	10	GE10	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	11	GE11	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	12	GE12	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	13	GE13	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	14	GE14	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	15	GE15	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	16	GE16	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	17	GE17	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	18	GE18	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	19	GE19	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A
<input type="radio"/>	20	GE20	Disabled	Disabled	Disabled	Disabled	Flooding	Disabled	2000000	128	Disabled	N/A

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

Small Business cisco Language: English Logout About Help

SG300-20 20-Port Gigabit Managed Switch

- Getting Started
- Status and Statistics
- Administration
- Port Management
- Smartport
- VLAN Management
- Spanning Tree
 - STP Status & Global Settings
 - STP Interface Settings
 - RSTP Interface Settings
 - MSTP Properties
 - VLAN to MSTP Instance
 - MSTP Instance Settings
 - MSTP Interface Settings
- MAC Address Tables
- Multicast
- IP Configuration
- Security
- Access Control
- Quality of Service
- SNMP

RSTP Interface Settings

Showing 1-20 of 20 per page

Filter: Interface Type equals to

Entry No.	Interface	Point-to-Point Operational Status	Port Role	Mode	Fast Link Operational Status	Port Status	
<input type="radio"/>	1	GE1	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	2	GE2	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	3	GE3	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	4	GE4	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	5	GE5	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	6	GE6	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	7	GE7	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	8	GE8	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	9	GE9	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	10	GE10	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	11	GE11	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	12	GE12	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	13	GE13	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	14	GE14	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	15	GE15	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	16	GE16	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	17	GE17	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	18	GE18	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	19	GE19	Disabled	Disabled	RSTP	Disabled	Disabled
<input type="radio"/>	20	GE20	Disabled	Disabled	RSTP	Disabled	Disabled

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.

GREEN ETHERNET Disabled

The screenshot shows the configuration interface for a Cisco SG300-20 20-Port Gigabit Managed Switch. The page title is "Small Business" and "SG300-20 20-Port Gigabit Managed Switch". The language is set to "English". The left sidebar contains a navigation menu with the following items: Getting Started, Status and Statistics, Administration, Port Management (selected), Port Settings, Link Aggregation, Green Ethernet, Properties (highlighted), Port Settings, Smartport, VLAN Management, Spanning Tree, MAC Address Tables, Multicast, IP Configuration, Security, Access Control, Quality of Service, and SNMP.

The main content area is titled "Properties" and contains the following settings:

- Energy Detect Mode: Enable
- Short Reach: Enable
- Port LEDs: Enable
- Power Savings: 80 %
- Cumulative Energy Saved: 0 Watt Hour
- 802.3 Energy Efficient Ethernet (EEE): Enable

At the bottom of the configuration area, there are "Apply" and "Cancel" buttons.

© 2010-2013 Cisco Systems, Inc. All Rights Reserved.



- Getting Started
- Status and Statistics
- Administration
- Port Management**
 - Port Settings
 - Link Aggregation
 - Green Ethernet
 - Properties
 - Port Settings**
- Smartport
- VLAN Management
- Spanning Tree
- MAC Address Tables
- Multicast
- IP Configuration
- Security
- Access Control
- Quality of Service
- SNMP

Port Settings

For the functions and/or parameters configured on this page to become effective, you may have to configure the corresponding global parameters on [Properties](#) page.

Global Parameter Status

Energy Detect Mode: Disabled Short Reach Mode: Disabled 802.3 Energy Efficient Ethernet (EEE) Mode: Disabled

Port Setting Table Showing 1-20 of 20

	Entry No.	Port	Energy Detect			Short Reach			802.3 Energy Efficient Ethernet					
			Administrative	Operational	Reason	Administrative	Operational	Reason	Cable Length	Administrative	Operational	LLDP Administrative	LLDP Operational	EEE on F
<input type="radio"/>	1	GE1	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	2	GE2	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	3	GE3	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	4	GE4	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	5	GE5	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	6	GE6	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	7	GE7	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	8	GE8	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	9	GE9	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	10	GE10	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	11	GE11	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	12	GE12	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	13	GE13	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	14	GE14	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	15	GE15	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	16	GE16	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	17	GE17	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	18	GE18	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	19	GE19	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	
<input type="radio"/>	20	GE20	Disabled	Disabled		Disabled	Disabled			Disabled	Disabled	Disabled	Disabled	

Unregistered Multicast (Wifi Friendly) : None

The screenshot shows the configuration interface for a Cisco SG300-20 switch. The page title is "Unregistered Multicast". A filter is set to "Interface Type equals to Port". Below the filter, there is a table of 20 ports (GE1 to GE20) with radio buttons for "Forwarding" and "Filtering". All "Forwarding" buttons are selected, and all "Filtering" buttons are unselected. The "Apply" button is highlighted.

Port	GE1	GE2	GE3	GE4	GE5	GE6	GE7	GE8	GE9	GE10	GE11	GE12	GE13	GE14	GE15	GE16	GE17	GE18	GE19	GE20
Forwarding	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
Filtering	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

IGMP

Small Business
 cisco SG300-20 20-Port Gigabit Managed Switch

Save cisco Language English Logout About Help

- Getting Started
- Status and Statistics
- Administration
- Port Management
- Smartport
- VLAN Management
- Spanning Tree
- MAC Address Tables
- Multicast**
 - Properties
 - MAC Group Address
 - IP Multicast Group Address
 - IGMP Snooping
 - MLD Snooping
 - IGMP/MLD IP Multicast Group
 - Multicast Router Port
 - Forward All
 - Unregistered Multicast
- IP Configuration
- Security
- Access Control
- Quality of Service
- SNMP

Properties

Bridge Multicast Filtering Status: Enable

VLAN ID: 1

Forwarding Method for IPv6:

- MAC Group Address
- IP Group Address
- Source Specific IP Group Address

Forwarding Method for IPv4:

- MAC Group Address
- IP Group Address
- Source Specific IP Group Address

Apply Cancel

Small Business
 cisco SG300-20 20-Port Gigabit Managed Switch

cisco Language English Logout About Help

- Getting Started
- Status and Statistics
- Administration
- Port Management
- Smartport
- VLAN Management
- Spanning Tree
- MAC Address Tables
- Multicast**
 - Properties
 - MAC Group Address
 - IP Multicast Group Address
 - IGMP Snooping**
 - MLD Snooping
 - IGMP/MLD IP Multicast Group
 - Multicast Router Port
 - Forward All
 - Unregistered Multicast
- IP Configuration
- Security
- Access Control
- Quality of Service
- SNMP

IGMP Snooping

IGMP Snooping Status: Enable

Apply Cancel

Entry No.	VLAN ID	IGMP Snooping Operational Status	Router IGMP Version	MRouter Ports Auto Learn	Query Robustness	Query Interval (sec)	Query Max Response Interval (sec)	Last Member Query Counter	Last Member Query Interval (msec)	Immediate Leave	IGMP Status
1	1	Disabled	v3	Enabled	2	125	10	2	1000	Disabled	Dis
2	2	Disabled	v3	Enabled	2	125	10	2	1000	Disabled	Dis

Copy Settings... Edit...

Pascal GUILLAUME
DV2
ZAC Euro Moselle
2 rue de la Gillière
57140 NORROY LE VENEUR

BP 726
57147 WOIPPY CEDEX

Tel : +33 (0)387 30 00 00
Fax : +33 (0)387 32 83 25

pguillaume@dv2.fr